




## **Avid Dock Link**



### **Attach Avid S1 or S3 to Avid Dock Link**

Easily and securely attach Avid S1 or S3 and Avid Dock together into one linked control surface. The Avid Dock Link plate easily attaches to the underside of your S1 or S3 surface, enabling you to connect your Dock right alongside it. Simply set the Dock into the link bracket and notches for a secure hold that won't budge during normal mixing use, but can be easily uncoupled at any time.